

ImageWriter LQ: Sheet Feeder Must Be Removed To Use Pin Feeder

This article last reviewed: 25 July 1988

Some users have asked if pin feed paper (computer paper with holes on the edge) can be used in the Imagewriter LQ while the cut sheet feeder is installed.

In fact, you must REMOVE the cut sheet feeder from the ImageWriter LQ before using computer paper.

If you have the cut sheet feeder installed, a sensor in the printer will register this fact. There is another sensor which indicates which type of paper feed is selected.

When the cut sheet feeder is installed, and the paper feed lever is set to tractor feed, conflicting signals will then be sent to the CPU in the printer. One says "don't use the sheet feeder", the other says "use the sheet feeder". The result is an error light.

Also, since the paper guide must move the paper from the sheet feeder into the proper position for the platen rollers to pull it into the platen paper path. Thus, if you use the cut sheet feeder, the paper guide must be in place to allow the printer to place the paper correctly for printing. Copyright 1988 Apple Computer, Inc.

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 3132