

## Tech Info Library

## LW Pro 810: Non-AppleTalk Packets in Data Stream (11/94)

Article Created: 15 February 1 Article Reviewed/Updated: 9 No		4	
TOPIC			
			rk, I noticed that a variety of rWriter Pro 810. How do I turn
DISCUSSION			
If you plan on using the RCF (order the manual "Apple LaserW Reference" (Apple Part Number	Writer Pro	810 TCP/I	
RCF can be accessed a couple of the printer's IP address has be maintenance port. This option further information on the main and Appendix A of Part 1 in the Configuration Manual. Once the for RCF are as follows:	peen set. T requires a intenance p ne LaserWri	he other winique Roort and cater Pro 8	way is by using the RJ-12 J-12 to mini DIN-8 cable. For abling, refer to Section 2.3.2
RCF: password RCF Super User mode: password	d = ACCESS d = SYSTEM		
Enable or Disable a Protocol S			
Below is listed the RCF comman protocol stack. Use these comm	nds you can		
SET SERVER option(s) DEFINE CHANGE			
	LAT NETWARE	[ENABLED ENABLED ENABLED ENABLED	DISABLED]   DISABLED]   DISABLED]   DISABLED]

Below is an example showing the disabling of TCP/IP:

change server authorized topip disabled

Specifying a protocol with no flag, enables that protocol and disables the rest. ALL enables all protocols. NONE disables them.

SET Modifies the current database and takes effect immediately.

Parameters are reset to permanent (DEFINEd or CHANGEd) values at the next login or initialization

DEFINE Modifies the permanent database and takes effect next login or initialization.

CHANGE Modifies both databases immediately.

Enable or Disable Announcement Broadcasts

-----

Announcement broadcasts may also populate the network such as DECnet MOP (Maintenance Operation Protocol) or bootp in TCP/IP. Use this command to specify server options.

SET SERVER option(s)
DEFINE
CHANGE

Option: ANNOUNCEMENTS [PROTOCOL] LAT [ENABLED | DISABLED]

TCPIP [ENABLED | DISABLED]

RCF [ENABLED | DISABLED]

Note: RCF enables or disables DECnet Mop.

Below is an example showing how to disable the DECnet MOP broadcasts:

change server announcements rcf disabled

Modifies the current database and takes effect immediately.

Parameters are reset to permanent (DEFINEd or CHANGEd) values at the next login or initialization

DEFINE Modifies the permanent database and takes effect next login or initialization.

CHANGE Modifies both databases immediately.

Enable or Disable Netware Broadcasts

-----

Netware broadcasts are different, use this command to specify the preferred Ethernet mode that IPX uses.

SET SERVER NETWARE IPX [DEFAULT | 802.3 | [ETHERNET\_II [ether\_type]]]

DEFINE [REDISCOVER [minutes]]

CHANGE [FAST [PRINTSERVER] ENABLE | DISABLE]

Below is an example showing how to disable Netware broadcasts:

change server netware ipx rediscover 0

DEFAULT IPX will try both 802.3 and Ethernet II. The first one found will be selected.

802.3 IPX will only look for 802.3 Ethernet frames.

ETHERNET\_II IPX will only look for Ethernet II frames.

ether\_type If Ethernet II is selected the user can specify the Ethernet type in ASCII hex. For example, the Netware default is 0x8137. The Ethernet type is not changed if this is not specified.

REDISCOVER Triggers the rediscovery process. This process queries the network for newly configured Novell Print Servers and starts all remote printers found.

minutes If specified with the REDISCOVER keyword this sets the automatic interval at which REDISCOVERY takes place. The range is from 0-14 minutes, 2 is the default and 0 disables periodic rediscovery.

FAST Some versions of Netware pserver when run on original PC class machines (4.77mhz) require this option to be disabled.

Article Change History:

09 Nov 1994 - Updated article to include more RCF commands and clarity.

25 Oct 1994 - Updated article to include more RCF commands.

Support Information Services
Copyright 1994, Apple Computer, Inc.

Keywords: knts

\_\_\_\_\_\_

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 14642