

A/UX: The network unreachable Remote Mount Error (8/94)

Article Created: 29 October 1990 Article Reviewed/Updated: 25 August 1994 TOPIC ------I tried to mount a remote file system and got the error: network unreachable DISCUSSION ------This could be because the Ethernet card or cable connection is not working correctly. Here are four troubleshooting steps: 1) Make sure that the Ethernet cable from the Ethernet card to the rest of the network is connected and seated properly and snugly. 2) Check that there is not a broken connection in the main network cable itself. 3) Check that cables do not show any physical signs of damage. Ethernet cables should not be crimped, bent, or squished. 4) Replaced all cables that show excessive wear. Article Change History: 25 Aug 1994 - Reviewed and updated. Support Information Services Copyright 1990, 1994 Apple Computer, Inc. Keywords: <None> This information is from the Apple Technical Information Library. 19960215 11:05:19.00 Tech Info Library Article Number: 6552