

## A/UX: Driver Needed for Ethernet Compatibility

| Article Created: 13 August 1991  |
|--|
| Article Change History   |
| 08/31/92 - REVIEWED  o For technical accuracy.   |
| TOPIC  |
| Does the correct EtherTalk driver installed into the Macintosh System folder make the Ethernet card compatible with A/UX? Does the A/UX kernel need to be modified for compatibility?  |
| DISCUSSION   |
| The Ethernet driver that you need to use with A/UX is called ae6. You add or remove this driver from A/UX via the newconfig(1M) command. You can check the man pages in A/UX for more information on this command. Copyright 1991 Apple Computer, Inc. |
| Keywords: <none></none>  |
| =======================================  |
| This information is from the Apple Technical Information Library.  |
| 19960215 11:05:19.00   |
| Tech Info Library Article Number: 8679   |