

Printing from Visicalc III

The driver file on the Visicalc III diskette is set up with two drivers: .PRINTER, which is the default printer driving the Silentype, and .QUME, the driver for the RS-232 port. Two ways to get output to the Qume are:

A. Use the System Configuration Program to rename the existing .PRINTER to .SILENTYPE, then rename .QUME to .PRINTER.

B. Send the information to the printer as if it were a file.	
For the Silentype:	For the Qume:
/P P	/P F .QUME
Then enter the lower right coordinate of printed. Apple Tech Notes	the part of the worksheet you want
Keywords: <none></none>	
=======================================	
This information is from the Apple Technical Information Library.	

19960215 11:05:19.00

Tech Info Library Article Number: 626