

EtherTalk: How To Determine Version Number

Article Created: 13 August 1991
Article Last Reviewed:
Article Last Updated:
TOPIC
What is the proper procedure for determining what version of EtherTalk a Macintosh is running?
DISCUSSION
To determine what version of the EtherTalk drivers you're using:
1. Open your System Folder
2. Click on the EtherTalk driver
3. Select Get Info.
4. The Get Info Box will appear along with the version number under "Version".
Copyright 1991 Apple Computer, Inc.
Keywords: <none></none>
=======================================
This information is from the Apple Technical Information Library.
19960215 11:05:19.00
Tech Info Library Article Number: 8680