

EtherTalk: How To Install for AppleTalk Phase 2 Compatibility

Article Created: 14 June 1991 Article Last Reviewed: Article Last Updated:
TOPIC
Where can I find a copy of the EtherTalk Interface driver that's compatible with AppleTalk Phase 2?
DISCUSSION
You need to run the Network Product Installer disk and tell it you want to install EtherTalk. When it asks for the disk, insert the EtherNet Installer Disk 2.0.1. This will install the AppleTalk Phase 2 drivers. Copyright 1991 Apple Computer, Inc.
Keywords: <none></none>
This information is from the Apple Technical Information Library.
19960215 11:05:19.00
Tech Info Library Article Number: 8420