

Power Macintosh 7100 CD Audio Connect Pinouts (5/95)

Article Created: 5 May 1995	
TOPIC -	
I need to build an audio cable for a non-Apple CD-ROM on the Power Macintosh 7100/66. What are the logic board connector pinouts?	
Pin	Signal
 1 2 3 4	CD in Left CD Common CD Common CD in Right
The log	gic board connector is a J19, this connector is located behind the drive
Support Information Services Copyright 1995, Apple Computer, Inc.	
Keywords: kppc	
This information is from the Apple Technical Information Library.	
19960215 11:05:19.00 Tech Info Library Article Number: 17709	