



# Tech Info Library

## Power Macintosh & CD-ROM: Want to Initialize Dialog (2/95)

Article Created: 9 Jun 1994

Article Reviewed/Updated: 27 February 1995

TOPIC -----

I am using a Power Macintosh with Audio CDs and when the CD is inserted, a dialog is displayed asking if I want to initialize the CD.

DISCUSSION -----

Check for control panel/extension conflicts by restarting with only the CD extensions and control panels installed. The Extension Manager can exclude all but the base System 7.5 extensions.

Usually this behavior can be attributed to conflicts with software that extends the functionality of the Macintosh file system and its ability to read foreign file formats. Make sure you have the Foreign File Access and Audio CD Access files in your Extensions folder.

One known control panel that causes this behavior is DOS Mounter from Insignia Solutions. It is similar to PC Exchange in that it allows the Macintosh to read DOS disks and CDs. If both PC Exchange and DOS Mounter are installed, the Macintosh will have this trouble with audio CD's. Remove either PC Exchange or DOS Mounter.

Article Change History:

27 Feb 1995 - Clarified possible causes of problem.

Support Information Services

Copyright 1994-95, Apple Computer, Inc

Keywords: kppc

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 15584