

Power Macintosh: Error Tones With Upgrade Card (6/94)

Article Created: 10 June 1994
TOPIC
After installation of the Power Macintosh Upgrade Card in the PDS slot of a Macintosh, the machine refuses to boot in either 68k or Power Macintosh modes. Instead, the Macintosh produces only error tones.
DISCUSSION
Receiving error tones after installing the Power Macintosh Upgrade card can indicate a problem with either the DRAM installed in the system or the card itself.
You may test this by removing the extra DRAM from the Macintosh. If the card now functions properly, the DRAM may not be within Apple specifications or could be installed incorrectly.
If the card continues to fail with DRAM removed, disconnect all devices attached to the SCSI port and test again. If the card continues to fail, try a replacement Power Macintosh Upgrade Card.
Support Information Services Copyright 1994, Apple Computer, Inc
Keywords: kppc
This information is from the Apple Technical Information Library.
19960215 11:05:19.00
Tech Info Library Article Number: 15607