

## Macintosh SCSI Hard Disk Drives: How Capacities Are Calculated

This article last reviewed: 30 March 1988

After a hard disk is formatted, the Finder shows the "available" storage in kilobytes. With a given drive, this number varies with the version of HD Setup software used. For example:

Dri	ve	HD	Setup 1.3	HD	Setup	1.5
HD	40SC		41,439K	39	Э,333К	
HD	80SC		76,911K	76	5,869K	

To calculate the drive's capacity in bytes, multiply the number of kilobytes (K) by 1,024. To calculate the drive's capacity in megabytes, divide the number of kilobytes by 1,024. The capacity of the drives after being formatted with HD Setup 1.5 is:

HD 40SC 39,333K = 40,276,992 bytes = 38.4MB HD 80SC 76,869K = 78,713,856 bytes = 75.1MB

The sizes of formatted drives varies between manufacturers, depending on the intelligence of the drive controller. Some drive controllers spare bad blocks automatically or allocate a range of blocks that can be swapped with bad blocks. It is the industry practice to quote the size of a formatted drive even though the size of the drive will vary depending on the operating system with which the drive is formatted. Copyright 1990 Apple Computer, Inc.

Keywords: <None>

\_\_\_\_\_

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 2796