



Tech Info Library

ADB Mouse: Sticking In The Down Position (9/95)

Article Created: 8 September 1995

Article Reviewed/Updated: 15 September 1995

TOPIC -----

Sometimes my mouse seems to stick in the down position. For instance, I can click the scroll arrow in a window, and the window keeps scrolling until I click the mouse again. How can I correct this problem?

DISCUSSION -----

The symptoms you are describing could be caused by either hardware or software problems. Attempt to eliminate software first, then troubleshoot your hardware.

Try these steps in the order presented. If a step fails to correct the problem, proceed to the next one.

Step 1

Restart your computer. Many times simply restarting fixes the problem.

Step 2

Restart and turn off all extensions. If the problem goes away, troubleshoot your extensions.

Step 3

Shut down your computer, but leave the power supply to the computer turned on. Switch off any SCSI devices and completely disconnect all Apple Desktop Bus (ADB) cables and devices attached to your computer. Wait at least 10 seconds, reattach the ADB cables and devices, and restart your computer.

WARNING:

Do not disconnect ADB devices while the computer is turned on.

Step 4

Zap (reset) the PRAM (Parameter RAM) by holding down the Command-Option-P-R keys at startup.

Step 5

Replace the ADB cables and devices.

Article Change History:

15 Sep 1995 - Made minor corrections.

Support Information Services

Copyright 1995, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 18560