

## ImageWriter II: Single Sheets of Paper Require Manual Feed 2/95

Article Created: 3 February 1995
TOPIC
Whenever I try printing to my ImageWriter II using single sheets of paper, the top margin is not what I specified in my application. How can I get the proper margin in my document?
DISCUSSION
This occurs when you select Automatic in the Print dialog. Instead, select Hand Feed or Manual Feed depending on the printer configuration. You should Automatic only when you are using tractor feed paper.
Support Information Services Copyright 1995, Apple Computer, Inc
Keywords: <none></none>
This information is from the Apple Technical Information Library.
19960215 11:05:19.00
Tech Info Library Article Number: 17122