



Tech Info Library

ImageWriter LQ: Troubleshooting Color Ribbon Problems

Article Created: 14 June 1991

Article Last Reviewed:

Article Last Updated:

TOPIC -----

When I print a multi-page, multi-color color document on an ImageWriter LQ, each page prints in one color only. Each subsequent page prints in a different color.

DISCUSSION -----

Your printer is behaving as though it has a solid black ribbon. When a black ribbon is installed, the ribbon moves one line every page to distribute the wear on the printer ribbon.

The switch that tells the printer whether the ribbon is black or color may be broken. Check the operation of this switch manually, then have an Authorized Reseller check it with an Ohmmeter.

Copyright 1991 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 8431