

LaserWriter: Clear Manually-Downloaded Fonts At End Of Print Job

This article last reviewed: 28 September 1988

Under normal operation, the LaserWriter automatically purges downloaded fonts at the end of each print job. Fonts are retained in memory only when they have been manually downloaded.

(The number of downloadable fonts varies with the size of the font files, type of laser printer, and amount of available memory. When using the LaserWriter, four to six fonts may be downloaded per print job.)

If the fonts are not automatically purged at the end of the print job, they must be cleared from memory manually -- either by turning the printer off and on, or by resetting the printer, which forces a test page to be printed. Copyright 1988 Apple Computer, Inc.

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 3318