

Macintosh SE: Kodak Data Show's White Wire Connection

This article last reviewed: 15 February 1990
TOPIC
I was upgrading the memory of a Macintosh SE that had a Kodak Data Show card installed. The clip on the white wire that connects the Kodak card to a chip on the Main Logic Board came off. I have two questions: which chip was it connected to and which pin on that chip?
DISCUSSION
The white wire connects to the GLU chip at D9 pin #19. If you are looking at that chip laying horizontally with the notch on the left, #19 is the second pin from the left on the top row. Copyright 1990 Apple Computer, Inc.
Keywords: <none></none>
This information is from the Apple Technical Information Library.
19960215 11:05:19.00
Tech Info Library Article Number: 5177