

Apple Scribe Printer: Pinouts & Switch Settings (10/94)

Article Created: 04 December 1984 Article Reviewed/Updated: 13 October 1994 TOPIC ------This article provides the DIP switch configurations for the Apple Scribe Printer. DISCUSSION -----Switch settings: 1 2 3 4 5* 6 7 8 Select Alternative Character Sets: Off Off Off American Italian On Off Off American Off On Off British On On Off Off Off On German Swedish On Off On French Off On On Spanish On On On Gen <LF> out after <CR>: yes On Off no Print Intensity: Normal On Off Low Baud Rate: 1200 On 9600 Off Handshake: XON/XOFF On DTR Off 2 3 5* 6 7 8 1 4

* Switch 5 is not used.

DB-25 Connector Signal Name 1 Frame Ground 2 Transmit Data (Tx) 3 Receive Data (Rx) 4 Request to Send (RTS) 7 Signal Ground 20 Data Terminal Ready (DTR) Article Change History: 13 Oct 1994 - Reviewed for technical accuracy, revised formatting. Support Information Services Copyright 1988-94 Apple Computer, Inc. Keywords: <None> _____ This information is from the Apple Technical Information Library. 19960215 11:05:19.00 Tech Info Library Article Number: 1036