

Newton Connection Kit for Windows: Using a Logitech Mouse (4/94)

| Article Created: 12 April 1994 |
|---|
| TOPIC |
| This article describes compatibility problems between the Logitech Mouse and the Newton Connection Kit for Windows. |
| DISCUSSION |
| When using the Newton Connection for Windows with a Logitech FirstMouse, the mouse cursor, or arrow, will travel across the screen in random direction without user interaction. |
| This is usually caused by a misconfigured Windows mouse driver. Change the configuration of the mouse using the Windows Setup program from "Microsoft or IBM PS/2 mouse" to "Logitech Mouse". |
| Support Information Services Copyright 1994, Apple Computer, Inc |
| Keywords: KNMP |
| |
| This information is from the Apple Technical Information Library. |
| 19960215 11:05:19.00 |
| Tech Info Library Article Number: 15114 |